

DIRECT FIXING

Screw each deck board with one screw directly through the bottom tongue at the middle of the deck board.

This way the board stays in place while the expansion & contraction can occur at both ends.

Screw the small or large T-Clip or Alu Rail on top of the single direct fixing.

In warmer climates, UPM ProFi recommends installation with Alu Rail only to avoid the deck boards bending excessively when hot.

